



EN | User Guide


Setting your room temperature

1. Your current room temperature is shown in the display. To set the temperature you want, just turn the dial right to increase and left to decrease. Each 'click' as the dial turns represents a 0.5°C change.



2. After five seconds the current room temperature will be displayed once again. The thermostat will then try to maintain your set temperature as accurately as possible.

You can check your set temperature by turning the dial one 'click' to the left or right. The set temperature will flash up for a few seconds, before returning to display the room temperature again.



Night-time temperature reduction

Overnight, or if you are out, it is best to set the thermostat to a lower temperature, as it will save you energy. In general a reduction of 5°C is recommended, but this will depend on your heating system and the amount of insulation in your home.

Replacing the batteries

The batteries should be replaced when the  symbol is displayed.

Remove the dial (1) and separate the thermostat (2) from the mounting plate (3). Replace the discharged batteries with two new AA alkaline batteries, then reattach the thermostat to the mounting plate and replace the dial.



Getting to know your display

Set Temperature Indicator

Means the figure on the screen is your set temperature, rather than your current room temperature.



Heating on

Means there is a requirement for some heating, so your boiler should either be on or cycling on/off.



Boiler Relay Connection

Means your thermostat is successfully connected to your Boiler Relay.



Internet Gateway Connection (optional)

Means your thermostat is successfully connected to your Internet Gateway.



Troubleshooting

Low batteries

If you see this battery icon then you need to replace the batteries right away.



No power to the thermostat

If the thermostat screen is blank after initial installation, then check the protective tab has been removed from the batteries. Otherwise, try replacing the batteries.

RF communication error

If these icons are flashing, then there may be an issue with the signal from the Boiler Relay. First check there is mains power to the Boiler Relay. If this does not resolve the problem, consult your installer.



Defective thermostat

If this icon is displayed then the thermostat is no longer functioning and will need to be replaced.



Remote Operation

The thermostat can be controlled remotely if it is bound to a Wireless Internet Gateway, type RFG100.

1. The Connected symbol is displayed if the thermostat is bound to the Gateway.



2. When the set temperature is changed remotely a square border will appear around the Connected symbol.



3. Other possible display symbols and their meaning:



Clock
A remote time schedule is operating, or a timed override has been set



Lock
The temperature setting has been fixed for an indefinite time



OFF
The thermostat has been switched off remotely (control is at the off temperature setting)



4. You can always check the temperature setting by turning the dial one click. Continue to rotate the dial to change the set temperature. This will cancel any setting made via the app, except when the lock symbol is displayed.

This is only required if the gateway is purchased separately. If the gateway is supplied with the thermostat it will already be bound to it.

Binding your thermostat to a RFG100 Internet Gateway

If you want to operate your Thermostat remotely or add scheduling then you will need to use the Honeywell RFG100 Internet Gateway and bind the thermostat to it.

To do this, please follow the full installation instructions in the RFG100 box, and at the relevant binding stage follow these steps to connect your thermostat:

1. Touch and hold the right-hand touch zone for about 10 seconds to activate the binding screen.



2. Briefly touch the right-hand touch zone once again to send the binding signal. The  and  symbols will flash until binding is successful.



3. With good reception, the green  LED on the Gateway will then light up to confirm successful binding.



4. After binding, the strength of the signal between the devices will appear on the thermostat for a few seconds. 1 equals the lowest strength and 5 the highest.



Then the normal screen will be shown, including a  symbol to confirm the Gateway and the thermostat are now connected.



5. Please refer to your Gateway instructions to learn how to create your online account and download our smartphone app.



Pittway Sarl, Z.A. La Pièce 4,
1180 Rolle, Switzerland

www.resideo.com Country of origin: UK

© 2020 Resideo Technologies, Inc. All rights reserved.
The Honeywell Home trademark is used under license from Honeywell International Inc.
This product is manufactured by Resideo Technologies, Inc. and its affiliates.

For support:

Resideo
200 Berkshire Place
Winnersh Triangle, Berkshire
RG41 5R
Phone: 0300 130 1299