# resideo Pressure Reducing Valves

# Braukmann D06F-LF

Lead-free pressure reducing valve with balanced seat

Standard pattern with set point scale

## **APPLICATION**

According EN 806-2 pressure reducing valves of this type protect household water installations against excessive pressure from the supply. They can also be used for industrial or commercial applications within the range of their specification.

By installing a pressure reducing valve, pressurisation damage is avoided and water consumption is reduced.

The set pressure is also maintained constant, even when there is wide inlet pressure fluctuation.

Reduction of the operating pressure and maintaining it at a constant level minimizes flow noise in the installation.

## **APPROVALS**

- DVGW
- SINTEF
- VA (ETA)

#### **SPECIAL FEATURES**

- LEAD-FREE: Pb content of all materials less than 0.1 %
- Inlet pressure balancing no influence on outlet pressure by fluctuating inlet pressure
- Up to size 1<sup>1</sup>/<sub>4</sub>" approved by LGA for low noise, Group 1 without limitations
- The valve insert is of high-quality synthetic material and can be fully exchanged
- The outlet pressure is set by turning the adjustment knob
- The set pressure is directly indicated on the set point scale
- The adjustment spring is not in contact with the drinking water
- Integral fine filter
- Easily retrofittable to convert valve to a reverse-rinsing filter combination
- Can be retrofitted with an inlet non-return valve
- All materials are UBA conform




# **TECHNICAL DATA**

Drinking water
1/2" - 2"
DN15 - DN50
16 bar
1.5 - 6 bar
3 bar
1 bar
30 °C

Note: Use the SM06T brass filter bowl, if the valve can be exposed to

UV radiation or solvent vapors.

## CONSTRUCTION



## **METHOD OF OPERATION**

Spring loaded pressure reducing valves operate by means of a force equalising system. The force of a diaphragm operates against the force of an adjustment spring. If the outlet pressure and therefore diaphragm force fall because water is drawn, the then greater force of the spring causes the valve to open. The outlet pressure then increases until the forces between the diaphragm and the spring are equal again.

The inlet pressure has no influence in either opening or closing of the valve. Because of this, inlet pressure fluctuation does not influence the outlet pressure, thus providing inlet pressure balancing.

## TRANSPORTATION AND STORAGE

Keep parts in their original packaging and unpack them shortly before use.

The following parameters apply during transportation and storage:

Parameter	Value
Environment:	clean, dry and dust free
Min. ambient temperature:	5°C
Max. ambient temperature:	55 °C
Min. ambient relative humidity:	25 % *
Max. ambient relative humidity:	85 % *

<sup>\*</sup>non condensing

# **INSTALLATION GUIDELINES**

#### Setup requirements

- Horizontal and vertical installation position possible
- Install shut-off valves
- The device downstream should be protected by means of a safety valve (installed downstream of the pressure reducing valve). In these cases the delivery pressure of the pressure reducing valve shall be set to at least 20 % below the response pressure of the pressure relief-valve according to EN 806-2
- The installation location should be protected against frost and be easily accessible
  - Pressure gauge can be read off easily
  - With clear filter bowl, degree of contamination can be easily seen
  - Simplified maintenance and cleaning
- Provide a straight section of pipework of at least five times the nominal valve size after the pressure reducing valve (in accordance with EN 806-2)
- Requires regular maintenance in accordance with EN 806-5

# **Installation Example**




Fig. 1 Standard installation example for the pressure reducing valve

- 1 Water meter
- 2 Shut-off valve
- 3 Check valve
- 4 Filtering unit
- 5 Pressure reducing valve

Connection sizes:	1/2"	<sup>3</sup> / <sub>4</sub> "	1"	<b>1</b> 1/4"	1 <sup>1</sup> / <sub>2</sub> "	2"
Distance in mm (W*):	55	55	60	60	70	70

<sup>\*</sup> Required installation distances between the centerline of the pipework and the surrounding in dependency of the connection size.


# **TECHNICAL CHARACTERISTICS**

## kvs-Values

Connection sizes:	1/2"	3/4"	1"	<b>1</b> 1/4"	1 <sup>1</sup> / <sub>2</sub> "	2"
k <sub>vs</sub> -value (m <sup>3</sup> /h):	2.4	3.1	5.8	5.9	12.6	12.0
IfBt designation:	P-IX 1582/I	P-IX 1582/I	P-IX 1582/I	P-IX 1582/I	- *	- *
DVGW registration number:	DW-6330 AT 2314					


<sup>\*</sup> Compulsory testing in sizes R  $^1/_2$  " to R 1  $^1/_4$ 

# **Pressure drop characteristics**



 $Fig.\ 2\ Pressure\ drop\ within\ the\ valve\ in\ dependency\ of\ the\ flow\ rate\ and\ the\ used\ connection\ size$ 

# **DIMENSIONS**



Parameter		Values					
Connection size housing:	G	3/4"	1"	11/4"	11/2"	2"	21/2"
Connection sizes:	R	1/2"	3/4"	1"	1 <sup>1</sup> /4"	$1^{1}/_{2}$ "	2"
Nominal size diameter:	DN	15	20	25	32	40	50
Weight:	kg	0.8	1.0	1.3	1.4	4.0	5.3
Dimensions:	L	140	160	180	200	225	255
	l	80	90	100	105	130	140
	Н	89	89	111	111	173	173
	h	58	58	64	64	126	126
	D	54	54	61	61	82	82

Note: All dimensions in mm unless stated otherwise.

# **ORDERING INFORMATION**

The following tables contain all the information you need to make an order of an item of your choice. When ordering, please always state the type, the ordering or the part number.

## **Options**

The valve is available in the following sizes: 1/2", 3/4", 1",  $1^1/4$ ",  $1^1/2$ " and 2".

- standard
- not available

		D06FLFA	D06FLFE
Max. operating temperature medium:	40 °C	•	•
Filter bowl:	clear	•	•
Connection type:	external threaded connection set on in- and outlet	•	-
	without external threaded connections	-	•

Note: ... = space holder for connection size

Note: Ordering number example for 11/4": D06F-11/4LFA

# **Accessories**

	Description		Dimension	Part No.			
6	M07M	Pressure gauge					
		Housing diameter 63 mm, rear connection th	ousing diameter 63 mm, rear connection thread G <sup>1</sup> / <sub>4</sub> "				
		Range: 0 - 4 bar		M07M-A4			
8-		Range: 0 - 10 bar		M07M-A10			
10 NULS		Range: 0 - 16 bar		M07M-A16			
		Range: 0 - 25 bar		M07M-A25			
	ZR06K	Double ring wrench					
		For removal of spring bonnet and filter bowl					
				ZR06K			
***	VST06-LFA	Lead-free connection set					
		Threaded connections					
			1/2"	VST06-1/2LFA			
			3/4"	VST06-3/4LFA			
			1"	VST06-1LFA			
			11/4"	VST06-11/4LFA			
			11/2"	VST06-11/2LFA			
			2"	VST06-2LFA			

# **Spare Parts**

Pressure Reducing Valve D06F-LF, from 2015 onwards

Overview		Description	Dimension	Part No.
	1	Spring bonnet comple	te	
			1/2" - 1"	0901515
			1" + 11/4"	0901516
<u> </u>			11/2" + 2"	0901518
	2	Valve insert complete	(without filter)	
			1/2" + 3/4"	D06FA-1/2LF
			1" - 1/4"	D06FA-1LF
			11/2" + 2"	D06FA-11/2LF
(2)	3	Union seal washer (10	pcs.)	
4)			1/2"	0901443
			3/4"	0901444
			1"	0901445
			$1^{1}/4$ "	0901446
			$1^{1}/_{2}$ "	0901447
			2"	0901448
	4	Blanking plug with O-		cs.)
			1/2" - 2"	S06K-1/4
	5	Replacement filter ins		
			1/2" + 3/4"	ES06F-1/2A
			1" + 11/4"	ES06F-1B
			11/2" + 2"	ES06F-11/2A
	6	O-ring set (10 pcs.)		
(5)			1/2" + 3/4"	0901246
			1" + 11/4"	0901499
6			11/2" + 2"	0901248
		Clear filter bowl with C	•	
			1/2" + 3/4"	SK06T-1/2
			1" + 11/4"	SK06T-1B
			11/2" + 2"	SK06T-11/2



Ademco 1 GmbH, Hardhofweg 40, 74821 MOSBACH, GERMANY Phone: +49 6261 810

Phone: +49 6261 810 Fax: +49 6261 81309